



C.V. BOOTS / C.V. BOOT KITS

The **C.V. Boots / C.V. Boot Kits Section** includes Inner and Outer C.V. Boots / C.V. Boot Kits by Application, Vehicle Model Identification Information, C.V. Boot Substitution Information, C.V. Boot Clamps, Grease and Tools. You will also find Technical Reference Guides including C.V. Boot Mold Numbers and Buyer's Guide.

Most **EMPI** C.V. Boots are Neoprene except where Silicone is noted. **EMPI** replaces Thermoplastic (Hard Plastic) Boots, both one piece and Inboard two piece Trilobal Boots (Boot & Adaptor), with a one-piece Neoprene Boot. Some Boot Kits have a Metal Flange, a Plastic Spacer or other components necessary for installation. These necessary components are **always** included in **EMPI** C.V. Boot Kits. Most Boots fit both Driver and Passenger sides of the vehicle. If the Catalog listing does not specify Driver or Passenger, the application listed is for both sides.

Packaging:

Most Kits come complete with C.V. Boot, Pack of Grease*, Installation Instructions and a set of Mounting Clamps. Installation Instructions include Technical Drawings and are written in English, French and Spanish. All are packaged in our distinctive **EMPI** 3-Color, Tri-Lingual Box.

Product may be purchased in attractive **EMPI** 3-Color Display Packaging or in "Bulk". To order Bulk product, simply look up the application by make, model and year and place your order using the **EMPI** part number listed for that application. If you wish to order Kits, just add a "D" to the part number.

Example:

- 86-2323-0 Inner Boot only for Toyota "X" Car, etc.
- 86-2323-D Boot Kit for Toyota "X" Car, etc.



*Some Inboard Tripods fit directly into transmission. These kits do not contain grease.